

# Specimen Index

## Index terms

## Links

### **A**

Air preheater 143

### **B**

Belly plate 105

Blowdown components 204

Blowdown line 169 225

Blowdown lines/valves 219

Blowdown piping 191

Boiler feedwater-pump impeller 225

Boiler peripherals 265

Boiler tubes 169

Bottom slag-screen tube 66

Brass pressure-gauge fittings 265

Bronze pump impellers 265

Burner nozzles 191

### **C**

Camera port 64

Chill tube 231 233

Circulating fluidized-bed boiler 214

Cold reheat line 174

Condensate line 226

Condensate return header 215

Condensate return line 119 191

<u>Index terms</u>	<u>Links</u>				
Condensers	265				
Condensing turbine	213				
Convection bank	116				
Convection wall	217				
Corner tube	213				
Crossover tube	23				
Cyclone burners	249				
 <b>D</b>					
Deaerators	169				
Diaphragms	204				
Downcomer	156				
Downcomer tubes	77				
Drain line	175				
 <b>E</b>					
Economizer	90	120	143	147	153
	186	198	216		
Economizer tube	20	169			
Economizer U-bend	212				
Ethylene-cracking furnace tube	91				
 <b>F</b>					
Feedwater heaters	265				
Feedwater pump	204	259	263		
Feedwater-pump impeller	76				
Feedwater tubes	169				
Fine turbine screen	25				
Fire tube	107				
Fire-tube boiler	118				
Fittings	204				

**Index terms****Links**

Flue-gas cooler	211
Flue-gas scrubbers	143
Front-wall tube	177

**G**

Generating tube	155
-----------------	-----

**H**

Heat exchangers	265
High-pressure feedwater heater	270

**I**

Impellers	204
Induced-draft fan	143

**L**

Latter-stage buckets	204
----------------------	-----

**M**

Main steam leads	204
Monel steam strainers	265

**N**

Nose section	163
Nose slope	166
Nozzle blocks	204

**P**

Pendant U-bend	24
Pipe elbows	204
Platen tube	166
Power boiler	63 179 231 233

<u>Index terms</u>	<u>Links</u>				
Powerhouse	53				
Primary superheater	24				
Primary-superheater bank	42				
Primary-superheater inlet	44				
Primary-superheater pendant	210				
Pump impellers	219				
 <b>R</b>					
Rear wall	41				
Recovery boiler	139	147	152	177	185
	230				
Reheater tubes	169	181	204	253	
Reheaters	198	204	209	237	257
Retractable blowers	192				
Riser tube	69				
Roof tube	138	198			
 <b>S</b>					
Screen tube	106	152	230	247	
Screen wall	251				
Secondary superheater	255				
Secondary-superheater outlet	132				
Secondary-superheater pendant	233				
Side wall	85				
Side-wall tube	103				
Soot-blower lines	169				
Stack	143				
Steam drum	181				
Steam line	235				
Steam supply line	185				
Steam-transfer lines	209				

<u>Index terms</u>	<u>Links</u>				
Superheater	39	54	115	179	187
	189	198	202	204	209
	237	253			
Superheater outlet	21				
Superheater outlet header	246				
Superheater tubes	169	181	192		
<b>T</b>					
Target-wall tube	26				
Transfer lines	204				
Turbine blades	204				
Turbine steam strainer	269				
<b>U</b>					
U-tube bundle	67				
<b>V</b>					
Valve stems	204				
Valves	204				
<b>W</b>					
Wall blowers	193				
Wall tube	75	86	100	140	154
	169	202			
Water-carrying tubes	157				
Water-cooled tubes	157	202			
Water supply lines	259				
Water tubes	181				
Waterlines	169				
Waterwall	40	52	64	88	164
	166	213			

# Industry Index

<u>Index terms</u>	<u>Links</u>				
<b>A</b>					
Automotive	235				
<b>B</b>					
Brewing	77				
<b>C</b>					
Chemical manufacturing	225				
Chemical plant	26				
Chemical process	67	76	90	120	
<b>F</b>					
Food processing	263				
<b>G</b>					
Gas products	39				
<b>P</b>					
Petrochemicals	189				
Pulp and paper	20	105	115	139	142
	147	152	177	185	212
	216	225	230	233	255
<b>R</b>					
Refining	53	211	215		

**Index terms****Links****S**

Steam heating	118			
Steel	40	75	156	226
Sugar	69	148		

**T**

Textile	107			
---------	-----	--	--	--

**U**

Utilities	25	41	44	52	63
	66	85	88	100	132
	134	138	163	166	174
	210	213	217	233	246
	249	257	269		

# Subject Index

## Index terms

## Links

### A

Acid corrosion ( <i>see</i> Low-pH corrosion)		
Acid-producing salts, and low-pH corrosion during service	83	
Acidic regeneration chemicals, and low-pH corrosion during service	83	
Acmite	16	18
Afterboiler erosion:		
cautions	209	
critical factors	205	
elimination of	208	
general description	205	
identification	206	
locations	204	
Air in-leakage, sources of	114	
Air preheater, as specimen location	143	
Alkali compounds, and coal-ash corrosion	129	
Alkaline-producing salts, and caustic corrosion	62	
All volatile water-treatment program	132	270
Alloyed steel	253	
Aluminum	265	
Aluminum bronzes	267	
Ammonia water-treatment program	246	
Analcite	16	
Antifoulant added water-treatment program	91	

<u>Index terms</u>	<u>Links</u>				
Antimony	267				
Applied stress	183				
Arsenic	267				
Ash, as fuel	132	138			
Ash content, effect of, on erosive metal loss	200				
ASTM D887-82	62	84	162		
Atomic hydrogen, and hydrogen damage	157				
Automotive industry	235				
 <b>B</b>					
Baffles	202				
Bark, as fuel	255				
Belly plate, as specimen location	105				
Black liquor, as fuel	20	23	139	147	152
	187	212	216	225	230
Blast-furnace gas, as fuel	40	76			
Blowdown components, as specimen location	204				
Blowdown line, as specimen location	169	219	225		
Blowdown piping, as specimen location	191				
Blowdown valves, as specimen location	219				
Boiler, oxygen corrosion in	112				
Boiler deposits, sources of	2				
Boiler feedwater-pump impeller, as specimen location	225				
Boiler peripherals, as specimen location	265				
Boiler salines, recommended concentration of	10				
Boiler tubes, as specimen location	169				
Bottom slag-screen tube, as specimen location	66				
Brass	265				
Brass pressure-gauge fittings, as specimen location	265				

<u>Index terms</u>	<u>Links</u>				
Brewing industry	77				
Bronze	76				
Bronze pump impellers, as specimen location	265				
Bulging:					
in long-term overheating	31	38			
in short-term overheating	48				
Burner nozzles, as specimen location	191				
Burnthrough ( <i>see</i> Excess penetration)					
<b>C</b>					
Calcium chloride, and low-pH corrosion					
during service	83				
Calcium sulfate	16				
Camera port, as specimen location	64				
Carbon-molybdenum steels	245				
Carbon steel	139	186	189	245	255
	257				
Cast iron	221	259	263		
Caustic corrosion:					
case histories	63				
cautions	63				
critical factors	58				
elimination of	60	62			
general description	57	58			
identification	60				
locations	57				
Caustic embrittlement	181				
Caustic gouging	57	60			
Caustic regeneration chemicals, and					
elimination of caustic corrosion	62				
Cavitation:					
case histories	225				

<u>Index terms</u>	<u>Links</u>			
Cavitation: <i>(Continued)</i>				
critical factors	220			
definition of	219			
elimination of	224			
general description	219			
identification	221			
localized nature of attack	222			
locations	219			
Chain graphitization, as form of long-term overheating damage	35			
Chelant corrosion:				
case histories	75			
cautions	74			
critical factors	73			
elimination of	74			
general description	71			
identification	73			
locations	71			
Chelant water treatment program	20	75	90	213
Chelants, attack of, on magnetite	71			
Chemical manufacturing industry	225			
Chemical plant industry	26			
Chemical process industry	67	76	90	120
Chill tube, as specimen location	231	233		
Chromium	253			
Chromium stainless steels	221			
Circulating fluidized-bed boiler, as specimen location	214			
Citric acid, as cleaning solution	101			
Cleaning solutions:				
citric acid	101			
mineral acid	100	105		

<u>Index terms</u>	<u>Links</u>				
Cluster porosity	238				
Coal, as fuel	21	24	41	44	52
	64	132	138	210	213
	217	233	247	251	257
	269				
Coal-ash corrosion:					
case histories	132				
critical factors	130				
elimination of	132				
general description	129				
identification	130				
locations	129				
Coal-particle erosion	197				
cautions	203				
critical factors	202				
elimination of	203				
general description	202				
identification	203				
locations	202				
Cobalt-based alloys	209				
Coke gas, as fuel	42				
Cold-end corrosion	202				
during service:					
case histories	147				
cautions	146				
critical factors	145				
elimination of	146				
general description	143				
identification	146				
locations	143				
Cold reheat line, as specimen location	174				
Concavity	241				

<u>Index terms</u>	<u>Links</u>				
Condensate contamination:					
and caustic corrosion	62				
and hydrogen damage	161				
and low-pH corrosion during service	84				
Condensate line, as specimen location	226				
Condensate return header, as specimen location	215				
Condensate return line, as specimen location	119	191			
Condenser in-leakage, and hydrogen damage	161				
Condensers, as specimen location	265				
Condensing turbine, as specimen location	213				
Congruent control water-treatment program	88	102	138	164	233
Congruent phosphate water-treatment program	103				
Convection bank, as specimen location	116				
Convection wall, as specimen location	217				
Coordinated phosphate water-treatment program	25	52	63	64	66
	67	85	106	163	179
	187	210	213	230	247
	249	251	255		
Copper alloys	265				
Copper deposits	13				
Corner tube, as specimen location	213				
Corrosion fatigue:					
definition of	170				
sequence of	170	172			
Corrosion-fatigue cracking:					
case histories	174				
cautions	173				
critical factors	172				
elimination of	173				

Index termsLinks

Corrosion-fatigue cracking: <i>(Continued)</i>		
general description	170	
identification	171	172
locations	169	
Corrosion rate, and temperature	130	
Cracking:		
cautions	244	
elimination of	244	
forms of	244	
identification	243	
( <i>See also</i> Corrosion-fatigue cracking; Root-pass cracking; Stress corrosion cracking)		
Creep resistance, and alloy content	254	
Creep rupture	254	
as form of long-term overheating damage	33	35
and short-term overheating	51	
Crossover tube, as specimen location	23	
Cupriferous alloys, dealloying of	266	267 269
Cupronickel	265	269
dealloying of	269	
Cupronickel tube, dealloying of	268	
Cyclic stressing	247	
Cyclic tensile stresses	172	
Cyclone burners, as specimen location	249	
<b>D</b>		
Deaerators, as specimen location	169	
Dealloying:		
case histories	269	
critical factors	267	
definition of	265	

<u>Index terms</u>	<u>Links</u>
Dealloying: <i>(Continued)</i>	
general description	265
identification	266
locations	265
Dealuminification	267
Denickelification	265
Departure from nucleate boiling (DNB):	
and caustic corrosion	58
and chelant corrosion	73
and elimination of caustic corrosion	62
and hydrogen damage	161
and low-pH corrosion during service	82
and stress-corrosion cracking	184
Deposit analyses, and low-pH corrosion	
during acid cleaning	98
Deposit-weight determinations, and low-pH	
corrosion during acid cleaning	98
Deposition:	
and caustic corrosion	59
and low-pH corrosion during service	83
Deposits:	
definition of	2
iron oxide	158
iron sulfate	148
potassium pyrosulfate	135
sodium hydroxide	158   167   186
sodium nitrate	184
sodium pyrosulfate	139
sulfur trioxide	144
Design gas velocity (fps)	199
Destannification	266   268

**Index terms****Links**

Dew-point corrosion:					
during idle periods:					
case histories	152				
cautions	151				
critical factors	149				
elimination of	151				
general description	149				
identification	150				
locations	149				
Dezincification	265				
layer-type	265				
plug-type	265				
Diaphragms, as specimen location	204				
DNB ( <i>see</i> Departure from nucleate boiling)					
Downcomer, as specimen location	156				
Downcomer tubes, as specimen location	77				
Drain line, as specimen location	175				
Drum pressure:					
65 psi	213				
100 psi	107				
150 psi	211				
155 psi	90				
175 psi	91				
210 psi	235				
350 psi	174				
400 psi	185	270			
425 psi	26				
450 psi	69				
485 psi	77				
570 psi	212				
600 psi	20	39	54	105	120
	147	152	189	263	

<u>Index terms</u>	<u>Links</u>				
Drum pressure: <i>(Continued)</i>					
620 psi	41				
700 psi	39	116			
750 psi	155				
800 psi	23	53	76	186	
875 psi	100	140			
900 psi	21	75	177	226	231
	233	251			
1200 psi	40	42	187	216	225
	230				
1250 psi	24	106	179		
1275 psi	214				
1400 psi	255				
1500 psi	63	67	102	247	249
	269				
1800 psi	52	210			
1900 psi	86				
2000 psi	64	85	166		
2075 psi	163				
2080 psi	166				
2100 psi	164				
2150 psi	138				
2200 psi	25	66			
2250 psi	213				
2400 psi	210				
2500 psi	132	217	233		
2700 psi	88				
2875 psi	257				
3800 psi	246				
Dry lay-up treatment program	115				
Ductile gouging, definition of	57				
Dye penetrants	184				

<u>Index terms</u>	<u>Links</u>				
<b>E</b>					
Economizer, as specimen location	90	120	143	147	153
	186	198	216		
Economizer tube, as specimen location	20	169			
Economizer U-bend, as specimen location	212				
Electrochemical corrosion	157				
Elephant hiding	178				
Erodent velocity	205				
Erosion	191				
case histories	210				
coal-particle	202				
falling-slag	203				
fly-ash	198				
preboiler and afterboiler	204				
soot-blower	192				
steam cutting from adjacent tube failures	196				
water-side and steam-side	209				
Erosive thinning	193				
Ethylene-cracking furnace tube, as specimen location	91				
Evaporation at waterline:					
and caustic corrosion	59				
and low-pH corrosion during service	83				
Excess penetration:					
definition of	239				
elimination of	241				
identification	239				
<b>F</b>					
Falling-slag erosion	197				
cautions	204				
critical factors	203				

<u>Index terms</u>	<u>Links</u>
Falling-slag erosion ( <i>Continued</i> )	
elimination of	204
general description	203
identification	204
locations	203
Feedwater heaters, as specimen location	265
Feedwater pump, as specimen location	204    259    263
Feedwater-pump impeller, as specimen location	76
Feedwater system, and erosion	205
Feedwater tubes, as specimen location	169
Fine turbine screen, as specimen location	25
Fire-side corrosion	121
coal-ash	129
cold-end, during service	143
dew-point, during idle periods	149
oil-ash	123
waterwall-fire-side	135
Fire-side mechanisms	191
Fire tube, as specimen location	107
Fire-tube boiler, as specimen location	118
Fittings, as specimen location	204
Flue-gas cooler, as specimen location	211
Flue-gas scrubbers, as specimen location	143
Fly-ash erosion	197
cautions	202
effect of ash content and velocity on metal loss	200
elimination of	201
general description	199
identification	200
locations	198

<u>Index terms</u>	<u>Links</u>				
Food processing industry	263				
Forming defects:					
case histories	230				
cautions	228				
critical factors	228				
elimination of	228				
general description	227				
identification	228	229			
locations	227				
fps ( <i>see</i> Design gas velocity)					
Free acid:					
concentration mechanisms of	82				
and low-pH corrosion	82				
Front-wall tube, as specimen location	177				
Fuels:					
ash	132	138			
bark	255				
black liquor	20	23	139	147	152
	187	212	216	225	230
blast-furnace gas	40	76			
coal	21	24	41	44	52
	64	132	138	210	213
	217	233	247	251	257
	269				
coke gas	42				
fuel oil	23	26	44	69	75
	148	225			
high-sulfur fuel oil	156				
hog fuel	24				
lime	214				
natural gas	26	39	225	263	
sand	214				

<u>Index terms</u>	<u>Links</u>				
Fuels: <i>(Continued)</i>					
waste gas	75	189			
waste heat	54				
wood chips	214				
Fuel oil, as fuel	23	26	44	69	75
	148	225			
 <b>G</b>					
Gas entrainment	220				
Gas products industry	39				
Generating tube, as specimen location	155				
Graphite	259				
Graphitic corrosion:					
case histories	263				
cautions	263				
critical factors	261				
elimination of	263				
general description	259				
identification	260				
locations	259				
Graphitization:					
critical factors	245				
definition of	245				
elimination of	245				
general description	245				
identification	245				
locations	245				
 <b>H</b>					
Heat exchangers, as specimen location	265				
Hematite formation	13				

**Index terms****Links**

High-pressure feedwater heater, as specimen location	270	
High-sulfur fuel oil, as fuel	156	
Hog fuel, as fuel	24	
Hydrazine water-treatment program	116	246
Hydrogen damage:		
case histories	163	
cautions	162	
critical factors	160	
elimination of	161	
general description	157	
identification	160	
locations	157	
Hydrolysis, induced by acid-producing salts	82	
Hydrolyzable salts	18	
<b>I</b>		
Impellers, as specimen location	204	
Inadequate joint penetration:		
definition of	242	
elimination of	243	
identification	242	
Incomplete fusion:		
definition of	241	
elimination of	241	
identification	241	
Induced-draft fan, as specimen location	143	
Industries:		
automotive	235	
brewing	77	
chemical manufacturing	225	
chemical plant	26	

<u>Index terms</u>	<u>Links</u>				
Industries: <i>(Continued)</i>					
chemical process	67	76	90	91	120
food processing	263				
gas products	39				
petrochemicals	189				
pulp and paper	20	105	106	116	139
	142	147	152	177	185
	212	216	225	230	231
	233	255			
refining	53	211	215		
steam heating	118	119			
steel	40	75	156	226	
sugar	69	148			
textile	107				
utilities	25	41	44	52	63
	64	66	85	88	100
	132	134	138	163	164
	166	174	210	213	217
	233	246	249	257	269
Iron oxides	12				
Iron sulfate	148				
<b>L</b>					
Latter-stage buckets, as specimen location	204				
Lime, as fuel	214				
Linear porosity	238				
Long-term overheating ( <i>see</i> Overheating)					
Low-alloy steel	253				
Low-excess hydroxide water-treatment program	100				

## Low-pH corrosion:

## during acid cleaning:

case histories	100
cautions	99
critical factors	98
elimination of	98
general description	95
identification	98
locations	95

## during service:

case histories	85
cautions	84
critical factors	82
elimination of	83
general description	81
identification	83
locations	81

**M**

## Magnesium chloride, and low-pH corrosion

during service	83
----------------	----

## Magnesium compounds, and eliminating oil-

ash corrosion	126
---------------	-----

## Magnesium phosphate 16

## Magnetic-particle inspections 184

## Magtite exfoliation, and erosion 209

## Main steam leads, as specimen location 204

## Materials deficiency:

case histories	255
cautions	255
critical factors	254
elimination of	255

<u>Index terms</u>	<u>Links</u>				
Materials deficiency: <i>(Continued)</i>					
general description	253				
identification	254				
locations	253				
Maximum allowable design temperature	30				
Metal burning ( <i>see</i> Thermal oxidation)					
Metal gouging, and hydrogen damage	162				
Metallurgy:					
alloyed steel	253				
aluminum	265				
aluminum bronzes	267				
antimony	267				
arsenic	267				
brass	265				
bronze	76				
carbon-molybdenum steels	245				
carbon steel	139	186	189	245	255
	257				
cast iron	221	259	261	263	
chromium	253	254			
chromium stainless steels	221				
cobalt-based alloys	209				
copper alloys	265				
cupronickel	265	269	270		
graphite	259				
low-alloy steel	253				
molybdenum	244	253			
phosphorus	267				
proprietary metals	209				
stainless steel	139	189			
titanium	209				
unalloyed steel	244				

<u>Index terms</u>	<u>Links</u>			
Metallurgy: <i>(Continued)</i>				
zinc	265			
Mineral acid, as cleaning solution	101	105		
Molybdenum	244	253		
Monel steam strainers, as specimen location	265			
Morpholine treatment program	116			
 <b>N</b>				
Natural gas, as fuel	26	39	225	263
Neutralizing amine water-treatment program	119			
Nickel oxide	13			
Nose section, as specimen location	163			
Nose slope, as specimen location	166			
Nozzle blocks, as specimen location	204			
Nucleate boiling	4	58		
definition of	3	58	82	
 <b>O</b>				
Oil-ash corrosion:				
critical factors	124			
elimination of	126			
general description	123			
identification	125			
locations	123			
Overheating:				
long-term:				
case histories	39			
cautions	38			
chain graphitization	35			
creep rupture	33	35		
critical factors	36			
elimination of	38			

**Index terms****Links**Overheating: *(Continued)*

general description	30	
identification	37	
locations	29	
thermal oxidation	32	
short-term:		
case histories	52	
cautions	51	
critical factors	48	
elimination of	50	
general description	47	
identification	48	
locations	47	
Oxygen corrosion	226	
case histories	115	
cautions	113	
critical factors	112	
elimination of	112	
general description	109	
identification	112	
locations	109	
sources of air in-leakage	114	
Oxygen scavenger water-treatment program	120	185

**P**

Parting ( <i>see</i> Dealloying)		
Patch-weld overlays	250	
Pendant U-bend, as specimen location	24	
Petrochemical industry	189	

<u>Index terms</u>	<u>Links</u>				
Phosphate water treatment program	21	39	40	44	53
	67	100	107	186	189
	212	216	225	231	233
	263	269			
Phosphorus	267				
Pipe elbows, as specimen location	204				
Platen tube, as specimen location	166				
Polymer water-treatment program	26	41	54	69	105
	118	120	140	211	226
	235				
Porosity:					
definition of	238				
elimination of	238				
identification	238				
Potassium pyrosulfate	135				
and temperature in waterwall-fire-side corrosion	135				
Power boiler, as specimen location	63	179	231	233	
Powerhouse, as specimen location	53				
Preboiler attack	191				
Preboiler erosion:					
cautions	209				
critical factors	205				
elimination of	208				
general description	205				
identification	205				
locations	204				
Primary superheater, as specimen location	24				
Primary-superheater bank, as specimen location	42				
Primary-superheater inlet, as specimen location	44				

<u>Index terms</u>	<u>Links</u>				
Primary-superheater pendant, as specimen location	210				
Pulp and paper industry	20	21	105	106	115
	116	139	142	147	152
	177	185	212	213	216
	225	230	231	233	255
Pump impellers, as specimen location	219				
 <b>R</b>					
Rear wall, as specimen location	41				
Recovery boiler, as specimen location	139	147	152	177	185
	230				
Refining industry	53	211	215		
Regeneration chemicals, and hydrogen damage	161				
Reheat piping, as specimen location	204				
Reheater tubes, as specimen location	169	181	253		
Reheaters, as specimen location	198	204	209	237	257
Residual stress	183	189			
Retractable blowers, as specimen location	193				
Riser tube, as specimen location	69				
Roof tube, as specimen location	138	198			
Root-pass cracking	241				
 <b>S</b>					
Salts	16				
Sand, as fuel	214				
Scaling temperature	254				
Screen tube, as specimen location	106	152	230	247	
Screen wall, as specimen location	251				
Seam defects, definition of	227				
Secondary superheater, as specimen location	255				

<u>Index terms</u>	<u>Links</u>
Secondary-superheater outlet, as specimen location	132
Secondary-superheater pendant, as specimen location	233
Selective leaching ( <i>see</i> Dealloying)	
Short-term overheating ( <i>see</i> Overheating)	
Side wall, as specimen location	85
Side-wall tube, as specimen location	103
Sintered deposit, layers of, in coal-ash corrosion	130
Slag inclusions:	
definition of	238
elimination of	239
identification	238
Slagging	202
Slag-type deposit, layers of, in coal-ash corrosion	130
Sodalite	18
Sodium compounds, and oil ash corrosion	124
Sodium hydroxide	158 167 186 189
availability of, and caustic corrosion	58
concentration mechanisms for	58
and elimination of caustic corrosion	62
and hydrogen damage	158 161
susceptibility of steel to attack by	57
Sodium pyrosulfate	139
and temperature in waterwall-fireside corrosion	135
Sodium sulfite water-treatment program	118
Soot-blower erosion:	
cautions	196
critical factors	193

**Index terms****Links**

Soot-blower erosion: <i>(Continued)</i>		
elimination of	195	
general description	192	
identification	192	
locations	192	
Soot-blower lines, as specimen location	169	
Stack, as specimen location	143	
Stainless steel	139	189
Steam blanket deposits	3	
Steam contamination:		
and elimination of caustic corrosion	62	
and hydrogen damage	161	
and low-pH corrosion during service	84	
Steam cutting:		
from adjacent tube failures:		
cautions	197	
critical factors	196	
elimination of	197	
general description	196	
identification	197	
locations	196	
Steam drum, as specimen location	181	
Steam-formed deposits:		
case histories	20	
cautions	19	
copper deposits	13	
critical factors	7	
deposit morphology	18	
elimination	19	
general description	2	
identification	10	12
iron oxides	12	

Index termsLinks

Steam-formed deposits: ( <i>Continued</i> )				
locations	1			
nickel oxide	13			
salts	16			
zinc oxide	13			
Steam heating industry	118			
Steam line, as specimen location	235			
Steam-side erosion	209			
Steam supply line, as specimen location	185			
Steam-transfer lines, as specimen location	209			
Steel:				
acid corrosion of	98			
oxygen corrosion of	109			
Steel industry	40	75	156	226
Stress-corrosion cracking:				
case histories	185			
cautions	184			
critical factors	183			
definition of	181			
elimination of	183			
general description	181			
identification	183			
locations	181			
Stress rupture ( <i>see</i> Creep rupture)				
Sugar industry	69	148		
Sulfur, and oil ash corrosion	124			
Sulfur compounds:				
and coal-ash corrosion	129			
and waterwall-fire-side corrosion	135			
Sulfur trioxide:				
and cold-end corrosion	143			
concentration of, and dew point	144			

<u>Index terms</u>	<u>Links</u>				
Sulfuric acid dew point	145				
and cold-end corrosion during service	146				
definition of	143				
Sulfuric acid vapor	143				
Sulfurous ash deposits, and dew-point corrosion					
during idle periods	149				
Superheater, as specimen location	39	54	115	179	187
	189	198	202	204	210
	237	253			
Superheater outlet, as specimen location	21	132			
Superheater outlet header, as specimen					
location	246				
Superheater pendant, as specimen location	233				
Superheater tubes, as specimen location	169	181	192		
Susceptible material, definition of	245				
 <b>T</b>					
Target-wall tube, as specimen location	26				
Temperature:					
and corrosion rate	130				
and pyrosulfates in waterwall-fire-side					
corrosion	135				
and vanadium compound formation	124				
Tensile stress	183				
Textile industry	107				
Thermal breakdown point, and low-pH					
corrosion during acid cleaning	99				
Thermal-degradation failure	255				
Thermal fatigue	176				
Thermal oxidation	32				
as form of long-term overheating damage	32				
Thermal stresses	4				

<u>Index terms</u>	<u>Links</u>				
Titanium	209				
Transfer lines, as specimen location	204				
Tubercles, identification of	113				
Tube waterlines, and elimination of caustic corrosion	62				
Turbine blades, as specimen location	204				
Turbine erosion	191	205			
Turbine steam stainer, as specimen location	269				
 <b>U</b>					
Ultrasonic testing	136	160	184		
Unalloyed steel	244				
Undercut:					
definition of	241				
elimination of	242				
identification	240				
Uniformly scattered porosity	238				
Utilities	25	41	44	52	63
	66	85	88	101	132
	134	138	163	174	210
	213	217	233	246	249
	257	269			
U-tube bundle, as specimen location	67				
 <b>V</b>					
Valve stems, as specimen location	204				
Vanadium compounds:					
and oil-ash corrosion	126				
sequence of formation	123				
temperature and formation of	124				
Velocity, effect of, on erosive metal loss	200				

<u>Index terms</u>	<u>Links</u>				
<b>W</b>					
Wall blowers	193				
Wall tube, as specimen location	75	86	100	140	154
	169	202			
Waste gas, as fuel	75	189			
Waste heat, as fuel	54				
Water-carrying tubes, as specimen location	157				
Water-cooled tubes, as specimen location	157	202			
Water-droplet impingement	204				
Water-formed deposits:					
case histories	20				
cautions	19				
copper deposits	13				
critical factors	7				
deposit morphology	18				
elimination	19				
general description	2				
identification	10	12			
iron oxides	12				
locations	1				
nickel oxide	13				
salts	16				
Water quality, influence of, on deposition	9				
Water-side deposition:					
and elimination of caustic corrosion	62				
and hydrogen damage	161				
and low-pH corrosion during service	84				
Water-side erosion	209				
Water supply lines, as specimen location	259				
Water-treatment program:					
all volatile	132	270			
ammonia	246				

<u>Index terms</u>	<u>Links</u>				
Water-treatment program: <i>(Continued)</i>					
antifoulant added	91				
chelant	20	75	90	213	
congruent control	88	102	138	164	233
congruent phosphate	103				
coordinated phosphate	25	52	63	66	85
	106	163	179	187	210
	213	230	247	249	255
dry-lay-up	115				
hydrazine	116	246			
low-excess hydroxide	100				
morpholine	116				
neutralizing amine	119				
oxygen scavenger	120	185			
phosphate	21	39	44	53	67
	100	107	186	189	212
	216	225	231	233	263
	269				
polymer	26	41	54	69	105
	118	120	140	211	226
	235				
sodium sulfite	118				
wet lay-up	116				
Water tubes, as specimen location	181				
Waterline formation, and hydrogen damage	162				
Waterlines:					
and low-pH corrosion during service	84				
as specimen location	169				
Waterwall, as specimen location	40	52	64	88	164
	166	213			
Waterwall-fire-side corrosion:					
case histories	138				
critical factors	136				

**Index terms****Links**

Waterwall-fire-side corrosion: <i>(Continued)</i>	
elimination of	137
general description	135
identification	136
locations	135
Weld spatter	245
Welded tubes, deficiencies in	227
Welding debris	245
Welding defects:	
case histories	246
cracking:	
cautions	244
elimination of	244
forms of	244
identification	243
critical factors	237
excess penetration:	
elimination of	241
identification	239
general description	237
graphitization:	
critical factors	245
elimination of	245
general description	245
identification	245
locations	244
inadequate joint penetration:	
elimination of	243
identification	242
incomplete fusion:	
elimination of	241
identification	241

Welding defects: *(Continued)*

locations	237
porosity:	
elimination of	238
identification	238
slag inclusions:	
elimination of	239
identification	238
undercut:	
elimination of	242
identification	240
welding debris	245
Wet lay-up treatment program	116
Wood chips, as fuel	214

**X**

X-ray fluorescence	156
--------------------	-----

**Z**

Zinc oxide	13
------------	----